





PROCESSOR
PCB
(3 DIAGRAMS)





1




OSCAR MIDI PCB.






UNMARKED POWER CONNECTIONS

74LS02 +5V Pin 14
74LS08 GND Pin 7


CONNECTIONS CARRIED VIA PROCESSOR PCB SOCKETS








AT




NOISE GENERATOR & TRIGGER IN/OUT






4

OSCILLATOR
FILTERS AND VCA





IC1 - IC5 = 4051B

TOP NOTE

OSCAR KEYBOARD PCB

